

## Poseidon MKVI Pre-dive checklist

		Pre-dive checklist
		Check for damage, dirt and deteriorations during assembly.
	1	Check that the battery is charged.
	2	Inspect electronics module, handset, cables, electric connections, HUD, pneumatics hoses and oxygen sensors.
	3	Mount top plate on top of scrubber, check O-rings (2 O-rings).
	4	Mount end plate in the bottom of scrubber, check O-rings and sponge (3 O-rings).
	5	Install scrubber into cartridge housing, tighten the four screws by hand.
	6	Attach BC and harness to cartridge housing.
	7	Mount counterlungs.
	8	Check valve.
	9	Check hoses, mouthpiece, T-valves and attach.
	10	Check pressure, analyze, and attach filled gas cylinders.

Figure 2-15. General Pre-Dive Checklists.

11	O2%psi/bar Diluent%psi/bar Helium%psi/bar
□ 12	Attach electronics module, tighten the two screws by hand.
□ 13	Mount the two first stages.
□ 14	Attach IP diluent supply hose to mouthpiece, tighten.
□ 15	Attach HUD on to mouthpiece.
□ 16	Attach IP diluent supply hose to inflator.
□ 17	Close OPV on right counterlung.
□ 18	Negative loop pressure test.
□ 19	Insert smart battery and conduct power-up self-tests (see Start up procedure).
<u> </u>	Prebreathe. It is very important to preform a full prebreathe for a minimum of 4 minutes, while pinching your nose.